9/17

F1G. 94

PROGRAM LOAD

STEP EXECUTION

F16.9C

WRITE TO STEP EXECUTION ENABLE

BIT OF CONTROL REGISTER

+GO

HINIT | Please add it

INTERNAL REGISTER READ - READ OF MONITOR RAM ON MEMORY MAP

FIG. 9D BREAKPOINT SETTING

WRITE TO BREAK ENABLE BIT AND BREAK ADDRESS BIT OF CONTROL REGISTER



11/17 (con't)

